

Workplan to remove contaminated soil from the culvert running under the railroad tracks.

Approach: excavation, removal and disposal of the contaminated sediments in the concrete culvert that runs under the railroad tracks.

Equipment: hand shovel, air knife utilizing only compressed air (no water)

Waste/spoils management: all materials will be placed into roll-off bins

Outcome: further success in the source control effort, delineation of the actual extent of impact of the rail bed.